

Assembly

- 1.) Set a drumhead on top of the bass drum wall with the rounded side facing up. Place a retaining ring on top and use six of the tension clips to secure it in place. Use the tuning tool to tighten all six of the tension clamps evenly.
- 2.) Repeat step 1 on the other side of the bass drum.



- 3.) Insert the spurs into the brackets on the bass drum. Set the drum on its side and adjust the length of the spurs so that the drum sits flat on the floor, and doesn't tip from side to side. Tighten the wing nuts to secure the spurs.



- 4.) Insert the bass drum mallet into the bracket on the pedal assembly and tighten the wing nut to hold it in place. Snap the hole in the metal bar over the post on the base and slide the bar forward so that the post fits into the notch. Do not tighten the wing nut on the clamp yet.
- 5.) Clamp the pedal assembly to the edge of the bass drum on the opposite side of the spurs. Tighten the wing nut to secure the clamp. You should now be able to depress the bass drum pedal, and the beater will strike the drum head.

- 6.) Remove the wing nut and felt washer from the cymbal post. Slide the cymbal onto the post (above the remaining felt washer), replace the other felt washer and secure with the wing nut.



- 7.) Insert the cymbal post into the bracket on to bass drum. Adjust the height and tighten the wing nut on the bass drum bracket to secure the cymbal post.

- 8.) Insert the long end of the tom-tom support into the bracket on the bass drum. Insert the other end into the bracket on tom-tom. Adjust the position of the drum and tighten the wing nut.



- 9.) Spread apart the legs of the tripod stand and tighten the wing nut to secure them. Insert the post of the snare drum holder into the tripod stand. Then, adjust the height and tighten the wing nut.

- 10.) Spread apart the arms of the snare drum holder. Adjust the length of the center arm to fit the snare drum and tighten the wing nut. Set the snare drum on top.