



SHELF INSTALLATION INSTRUCTIONS

THESE ARE GENERAL INSTRUCTIONS ONLY

- CUT A WOOD MOUNTING CLEAT (2 x 3 LUMBER WORKS WELL) SEVERAL INCHES SHORTER THAN THE SPACE IN BACK OF SHELF, ADJUST CLEAT TO A LEVEL POSITION AND SECURE TO WALL
- PREDRILL HOLES, AT A 45° ANGLE , IN THE TOP SHELF FOR SCREWS OR #10 FINISH NAILS
- AT A 45° ANGLE, SCREW OR NAIL THROUGH THE TOP SHELF INTO THE WOOD CLEAT
- ONCE THE SHELF IS SECURED, CAULK ANY SEAM BETWEEN THE SHELF & WALL -- USE MASKING TAPE IF THE SHELF TO BE FINISH STAINED AFTER INSTALLATION