

DiCAPac waterproof cases fitting guide

Updated 09/08/06

<i>Model</i>	<i>WP-100</i>	<i>WP-300</i>	<i>WP-500</i>	<i>WP-400</i>
Canon	PowerShot SD450, SD400, SD300, SD200, SD600, SD630 SD650	PowerShot SD700 IS, SD600, SD550, SD500*, SD430, S410, S400, S330, S300, A410, A420, A430	PowerShot A10, A20, A30, A40, A50, A60, A70, A75, A80, A85, A95, A510, A520, A530, A540, S30, S40, S50, S60, S70, S80	Canon PowerShot A400, SD100, SD110, S200, S230, S100, S110, SD30, SD20, SD10 Olympus Stylus Verve Digital, Stylus Verve Digital S, C-315 Sony Cybershot DSC S40, L1, S600 Other Toshiba Alegretto 3330, Hyundai DC-4300
Casio	Exilim EX S600, S500, S100, Z60, Z57, Z50, Z55, Z40, Z30, Z4, Z3, Z500, Z600, Z5, Z1000, S600-D, Z700	Exilim EX Z4, Z10, Z110, Z120, QV R61, R51, R41, R40, R4, R3, Z750, Z850, Z770, Z70	Exilim EX P700, P600	
Panasonic	DMC FX9, FX8, FX7, FX5, FX2, FX1, F1, F7, FX01	LS2, FX50, FX07	DMC LX1, LZ1, LZ2, LS1, LC80, LC70, LC50, LZ3, LZ5, TZ1	
Fujifilm	F455Z, F450, F440, F460, F470	Finepix F10 zoom*, F11 zoom*, A345, A350, F410, F420, F650, F30, V10, A400, A500, A600, A360, F20	Finepix E510, E500, A310, A330, A340, A600, A203, A303, F601, E900, F650, E550	
HP		M307, M407, R507, R607, R707, R717, E317, E327, R927	M517, 635, 735, 935, 812, R817, R818, M425, M525, M527	
Nikon		Coolpix 4600, 5600, 3200, 2200, 2100, 3100, 3700, 4100, 2200, 7900*, 5900*, 4200*, 5200*, 7600*	Coolpix 2000, 2100, 2200, 3100, 3200, 4100, L1, L2, L3, L4, L5, L6, P1, P2, P3, P4	
Olympus	Stylus 300/400/410/600/710, D-590, D-630, Ferrari DIGITAL MODEL 2003, FE-150, FE-190	Stylus 500/800 Digital, D-595, D-545, D-580, D-575, D-535, D-540, C-315, C-50, FE-120, FE-130, FE-140, Stylus700/740/810/750/1000, FE-180	C-1, D-100, C-2, D-230, D-40, D-510, C-300, C-7000, D-560, FE-100, FE-110, SP-310, SP-350, SP-320, FE-115, FE-170	<i>WP-600</i>
Pentax	Optio S5z, SVi, SV, S5i, X, S4i, S4, 50, S, S5n, S6, A10, T10, S7, A20	Optio S45, S55, S60, S50, S40, 330RS, 430RS, 30, 330, 430, 60, E10, M10, M20	Optio S30, 33LF, 33L, 330GS, 230, 750Z, W20	Canon A610, A620, A700, A710

For latest digital camera compatibility list visit www.goshotcamera.com or www.protectmycamera.com

The product specification and physical appearance are subject to change without notice.

DiCAPac® is a registered trademark of Dicapac Corporation. The other trademarks and brand names appearing in this brochure are trademarks or registered trademarks of their respective owners.

DiCAPac waterproof cases fitting guide

Updated 09/08/06

<i>Model</i>	<i>WP-100</i>	<i>WP-300</i>	<i>WP-500</i>	<i>WP-700</i>
Samsung	Digimax U-CA5, U-CA4, U-CA3, L55W, L50	Digimax 410, V700, V800, A400, A502, A55W, A50, A40, A7, A6, A5, A4, V6, V5, V4, V3, S500, S600, S800, NV10	Digimax 530, 430, 370, 360, 420, V70, V50, V40, UX4	Nikon Coolpix S1, S2, S3, S5, S6, S7c, S9
Sanyo	Xacti DSC S6	Xacti VPC S3, S4, S1, S5, S60	Xacti AZ1 MZ1 MZ2 MZ3 AZ1	Olympus Ferrari DIGITAL MODEL 2004, Stylus725/730
Sony	Cybershot DSC P100, P120, P200, N1, W30, W70, W100, W40, W50	Cybershot DSC P150	Cybershot DSC S60, S90, P92, P73, P72, P71, P41, P10, P9, P8, P7, P5, P2, P1, W7, W5, W1, W12, V1	Sony Cybershot DSC T7, T33, T3, T11, T1, T5, T9, T30, T10
Minolta	DiMAGE E500	KD-200 zoom, KD-300 zoom	DiMAGE F100, F200, F300, KD-3300, E323	Fujifilm Finepix Z1, Z2, Z3
Kodak	V530, V550	LS 755, LS 743, LS 753, LS 633, Easyshare ONE, C643, C663	CX 7300, CX 7530, CX 7430, CX 6230, CX 6330, CX 7220, DX 7630, DX 7440, DX 6440, DX 6340, DX 4530, DX 4330, LS 443, C340, C360, C433, C743, Z730	Minolta DiMAGE X1, X31, Xg, X20, Xt, X
Kyocera		Finecam S3, Yashica EZ-5030/5031	Finecam L3, L30, L3v, L4, L4v, S4, S3R, S5R, S3L	Samsung Digimax i5, #1, K50/ D512S, NV3
Ricoh		Caprio RZ1, R1, RR630, RR660	GX8, GX, RG Digital, RX, G4 wide, RR30	Casio Exilim EX M20, M1, M2, S20, S3, S2, S1
Other	Rollei Prego DP4200, BenQ DC E53 / 520 / 510, Hitachi Imega HDC-531, Leica C-Lux1	Minox DC8111, Rollei Prego DP8300 / 6300 / 5300 / DT3200, Mach Power DX-550, Polaroid PDC3370, Practica DCZ4.3, BenQ DC C40 / C50, Toshiba Alegretto 3310, Epson L-400 / L-300	Practica DCZ4.4, Toshiba PDR5300, Premier DC 2302 / 3306 / 5330, Kenko Z510, BenQ DC 5330 / S30, Kocom KDC-330, Hyundai HD-530, Hitachi Imega HDC-331, Vivitar 5385	Other Che-ez Fox Z2, Che-ez Fox Z3, Che-ez moni-me, HP R725/R727

For latest digital camera compatibility list visit www.goshotcamera.com or www.protectmycamera.com

The product specification and physical appearance are subject to change without notice.

DiCAPac® is a registered trademark of Dicapac Corporation. The other trademarks and brand names appearing in this brochure are trademarks or registered trademarks of their respective owners.