



Instructions for C6000 Police Type Camera



Welcome

Thank you for purchasing the new top of the line C6000. The following product manual will help you to install and operate your new device. Please be sure to fully read the directions before proceeding to use your new C6000.

Operation

- 1.) Before using this product please ensure that all accessories were included in the packaging and that the product is fully charged before use.
- 2.) Ensure that the device is not locked by pushing the **HOLD** switch to the down position. Then press the power **ON** button. The power on indicator light should come on when the initialization is complete the light will turn back off, indicating the machine is in its normal state.

3.) To record press **REC** button, the work indication light should turn on. Upon pressing the **STOP** button, recording will cease, and the file will be saved to your SD card. Note: This device supports up to 2GB SD cards.

4.) This device has an infrared mode that will allow the unit to record clearly in nighttime situations. To activate the night time shooting mode, press the ☀ and the indicator should light up. The video should now record in black and white.

5.) To charge the device simply connect the USB cable to your device then to the USB power adapter and plug the unit into a standard wall outlet. The indicator light will remain lit while charging.

Note: Due to the exposed nature of the camera lens it can at times get dirty. If you are experiencing blurry or sub-par image quality, please be sure to gently clean the camera lens with a soft cloth.