




## Instructions for DV1000P Camera Pen



### Welcome

Thank you for purchasing the new top of the line DV1000P. The following product manual will help you to install and operate your new device. Please be sure to fully read the directions before proceeding to use your new DV1000P Camera Pen.

Please be sure to check that all the accessories are present with your DV1000P and be sure to fully charge the device before using it.

### Operation

1.) To turn on the DV1000P and begin shooting, simply push the button on the top for 3 seconds. The indicator light will turn yellow as the pen starts up. When the light turns blue the device is fully booted and will begin recording automatically.

2.) To stop recording simply press the button at the top of the pen once more and the indicator light will change to yellow. The pen will automatically stop recording and go into a standby mode. Please note that if the pen receives no commands for longer than a one minute duration while in standby mode it will automatically shut itself off. A simple single button press can again toggle the record mode.

3.) To turn off the device simply press and hold the button down for several seconds. The indicator light will turn off when the pen deactivates.

### **File Transfer and Charging**

1.) To connect the DV1000P to a PC all you have to do is pull it apart revealing its USB plug, push this into an available port on your PC and it should automatically detect the device. While the device is connected to the PC you will be able to move files off of it and onto your PC and the pen will automatically begin charging itself for as long as it remains plugged in.

2.) When the indicator light turns red that is a sign that the battery is low on the pen. When you begin charging the device (either via connection to a PC or with the supplied adapter) the indicator light will turn yellow and blink, when the light remains solid, the device is fully charged.