



Tie-Cam User Manual

● Included Product Accessories

- Tie camera
- USB cable
- Remote Control
- User manual CD
- Charger

● Picture & Button Overview



1. Power on/off
2. Camera
3. USB Port
4. LED
5. Remote Control

● Technical Data

- 1) Functions: records video and audio, can be used as a USB drive
- 2) Video resolution: 640 x 480 (AVI)
- 3) Internal Memory: 4GB
- 4) USB: 2.0
- 5) Charging time: 4-5 hours
- 6) Power supply: Internal Li-Ion battery

7) Operating System: Automatic detection with Windows ME/ 2000/ XP/ VISTA or above (Windows 98 requires drivers to be installed)

● Operation

● Turn on

After opening the zipper on the tie, push the power switch to the “ON” position, the camera will power up to power-saving mode.

◆ Record video

1) While in power-saving mode, press the remote control button for 2 seconds, the green light will come on, after 2 seconds the green light will blink which indicates that the camera is recording.

2) Press the remote control again to stop recording and save your footage. The green light will stop blinking and remain steady, the camera will then be in standby mode.

Attention: If you do not operate the Tie-Cam for 30 seconds, the green light will turn off, the camera will then enter power-saving mode.

◆ Switch off

Under standby mode or power-saving mode, push the power to “OFF” position, the camera will turn off. **Attention:** In order to save power, please turn off the unit when you don't need to use the product.

◆ Charging

While the unit is turned off, connect the camera via USB with the charger, the green indicator light will turn on. The green light turns off when it is fully charged.

◆ Playback

After recording switch on the camera and while it is in standby mode, the connect the camera to the computer via USB cable, the files can then be played in the computer.

◆ Setting the time

When using the device for the first time, you can set the time of video as follows:

1) Connect the camera to your PC via the USB connection

2) Create a new “PHTIME.txt” file in the main directory of the device

3) Enter the time in the following format in the file: 2009-12-12 12:12:12

5) When you start up the device again, the time should be correctly “stamped” according to your file.

Attention: Please keep the power on when you set the time, otherwise it will reset to the default time.

● **Attention**

- 1) When the battery begins to die while taking video the system will save the video data first, then shut down automatically.
- 2) When taking video continually, the system will automatically generate a new video file after each operation.
- 3) To get the most out of the included high-capacity Polymer Li-Ion battery, please be sure to fully charge and let the battery fully drain before recharge, for the first 5 times that you use it.