




## Instructions for Tiny Stick Lighter DVR



### Welcome

Thank you for purchasing the new top of the line Tiny Stick Lighter DVR. The following product manual will help you to install and operate your new device. Please be sure to fully read the directions as well as charge the device before proceeding to use your new Tiny Stick.

### Operation

1.) To turn the device on, press down and hold the On/Off button for five seconds. The red and blue indicator lights will both come on at the same time and then only the blue light will remain on, indicating that the device is recording. **Note:** If the device is in photo mode the red light will instead blink.

2.)To stop video recording, press the on/off button briefly. The red light will come on indicating that it is in standby mode. When you are ready to begin recording once more, simply press down the on/off button briefly once more.

3.) To switch video modes, put the device into standby mode, remove the yellow cap and flip the switch to the desired mode. Replace the cap and press down the on/off button to resume taking photos or video. **Note:** When taking photos, remember to pause a moment before each picture.

4.) To turn the device off, hold down the on/off button for several seconds, the indicator lights should turn off. **Note:** If you are recording currently when you turn the device off, it will automatically save your data before turning off.

5.) To recover your data from the device, simply remove the yellow cap exposing the USB plug. Plug this into your PC and it should be automatically recognized, allowing you to move your data off the device. When watching the footage either KM Player or VLC are recommended.