

W2MDB MP3 Watch Manual



Welcome

Thank you for purchasing the new top of the line MP3 Watch. The following product manual will help you to operate your new device. Please be sure to fully read the directions as well as fully charge the device before proceeding to use your new MP3 Watch.

1.) To charge your watch, simply attach the USB cable to the included charger and plug the headphone style jack into the watch. The green light on the device will indicate that it has fully charged. (This should take about 8 hours)

Light Indicators

When you first turn the unit on, you should see three lights: red, blue, and green. These lights will cycle through as the unit powers up. A steady green light indicates MP3 mode, a slow flashing indicates the unit is in suspend mode.

If the light is a solid blue, the unit has stopped recording, while a slow flash indicates the unit is in suspend mode.

If the light on the unit is solid red, it is currently recording.

Operation

Note: To reset the unit, press down both the Stop/Play button as well as the Rew/Vol – buttons.

To turn the unit on briefly press the On/Off button and the unit should default to the MP3 suspended state.

To turn the unit off, simply hold down the On/Off button until the lights cycle through.

For the MP3 mode, if the green light is solid it is in the stop state, if the light is instead a steady blue, it is in record mode. While in these modes, the FF/RW functions can be achieved by pressing those buttons down briefly, while if you wish to adjust the volume holding the buttons down will cause the volume to increase or decrease incrementally.

When in the MP3 mode, pressing the EQ button will cycle through pre-set equalizer settings of ordinary, pop, classical, rock, and jazz.

Recording:

When the blue light on the device is on and steady, press the EQ/Rec button. The light should turn green and begin to blink, indicating it has begun recording.

If you wish to pause your recording at any time, simply press the Play/Stop button once to stop recording, another quick press will resume recording.

When you are finished recording and wish to save your data, simply hold down the EQ/Rec button until the light turns a steady yellow. If you briefly press the Play/Stop button at this point the device will play back your recording.

Computer Interface

To connect your device to the computer simply attach it using the included USB cable. Any systems later than Windows 98 should automatically detect and install drivers for the device, allowing you to access it as a drive under My Computer. Within this drive you will find all of your data.

